



## Assembly Instructions

### Tools Required

- Screw Gun
- 5/32" Hex Bit
- Drill Bit Extension
- Phillips Drill Bit

### Parts List: (per workstation)

- (1) Urban Edge Top
- (1) Base Cabinet
- (2) Heavy Duty Non- Locking Casters
- (20) 1/4"-20x40 LP Connector Bolts
- (2) Heavy Duty Locking Casters

Before you begin, please make sure all parts and proper quantities are included. Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding damages or if you have any questions, please call 800.242.2303.

- 1** With base cabinet laying on it's side, align caster with the pre-drilled holes.
- 2** Use LP connector bolts to attach casters to the base cabinet.
- 3** Use a 5/32" hex bit and a drill extension to fasten each bolt.
- 4** Repeat for each of the four casters.
- 5** Unscrew each arch pull handle using a phillips drill bit and a screw gun.
- 6** Reattach with arch pull handle facing out.
- 7** Place Urban Edge top onto base cabinet and align with pre-drilled holes.
- 8** Open base cabinet doors. Insert LP connector bolts up into the top through the base cabinet.
- 9** Use a 5/32" hex bit and a screw gun to fasten the bolt.
- 10** Proceed to the back of the cabinet, on the opposite side, to attach the second bolt.
- 11** Repeat these steps for the remaining two sides.



## Hardware List



**Heavy Duty Locking Caster**



**Heavy Duty Locking Caster**



**LP Connector Bolt**